

V Lectern Assembly Instructions

1. Place base plate on floor, and connect the posts with the hex (allen) key provided. Use the countersunk screws.

2. Wrap the MDF side around the base former, starting in the middle of the straight side.



3. Place the top former in to the top of the MDF wrap.

4. Place the lectern top in position and insert the non-countersunk screws with the hex (allen) key provided.



5. The lectern is now complete.

